



96P-24V


INSTALLATION INSTRUCTIONS (DC CONNECTION)

- 1 Plug power supply into FML or other compatible DC plug accessory
- 2 Connect two prong power feed to transformer box





3 Plug power supply into standard electical outlet



Note: LED tape wattage is not to exceed wattage of power supply. Double check before installation!


Questions/Support | 800-789-3810 | quotes@kelvix.com




96P-24V


INSTALLATION INSTRUCTIONS (HARDWIRE CONNECTION)


- 1) Remove DC plug from end of power supply
- 2) Observe polarity and connect freshly cut end to pre-installed LED power feed





- 3 Connect two prong power feed to transformer box
- Plug power supply into standard electical outlet





Note: LED tape wattage is not to exceed wattage of power supply. Double check before installation!

Questions/Support | 800-789-3810 | quotes@kelvix.com